

# Bastron



Echap	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11	F12			
2	1 &	2 é ~	3 " #	4 ' {	5 ( [	6 -	7 è `	8 _ \	9 ç ^	0 à @	° °	~ ~	+ +	←	
← Tab →	A	Z	E €	R	T	Y	U	I	O	P	^	£	µ	*	
Verr Maj	Q	S	D	F	G	H	J	K	L	M	% ù	←	↳	↵	
↑	> <	W	X	C	V	B	N	? ,	. ;	/ :	§ !	↑			
Ctrl	Win <sup>cmd</sup>	Alt <sup>option</sup>						Alt Gr	Fn		Ctrl				

<b>1</b> USB	<b>2</b> 2.4G	<b>3</b> BT	Touchpad		
Impr écran Sys	Verr Num	/	*	-	+
Inser		Pause Attn	7 	8 ↑	9 ↑
Suppr	Fin	Arrêt Défil	4 ←	5	6 →
↑	↑	↓	1 Fin	2 ↓	3 ↓
←	↓	→	0 Inser	.	Suppr